FOSCAM®

Quick Installation Guide

Indoor FHD IP Camera

Model: C2

You can download the QIG in other languages from http://www.foscam.com/download/QIG.html .

V1.4

1 Installation Notice

Package Contents



Security Warning

- Please change the password of your camera regularly, and use the combination of numbers, letters and special characters.
- We recommend you to update your camera to the latest firmware every three months, in order to ensure the safety of your camera and have a better product experience.
- Please keep the username and password of your camera safe, and do not tell them to others.

2 Physical Description

Front View



Rear View



3 Download APP

To install the Foscam APP on your smartphone, you can choose either of the following methods:

■ **Scan QR code**

If you have a QR Code APP on your smartphone, scan the code below.

Foscam

■ **Download from App store**

You can search the term "Foscam" directly on the APP Store or Google Play Store. Then find the APP that appears with the same icon as shown above, and install it to your smartphone.

Before you continue, please note:

- Make sure your wireless router is enabled DHCP, and connected to internet.
- Make sure your smartphone is connected to your wireless router and located near the camera.

Please note:

The camera has a 1080P video output. Make sure you have a much smoother video experience on the smartphone. It recommends that the smartphone has the following configuration:

- IOS: system version 8.1 and above.
- Android: systetem version 4.1 and above, and the smartphone has a Graphics Processing Unit (GPU) function.

4 Add IP Camera

There are two methods, wired and wireless connection, for you to add IP camera via Foscam APP. You can choose either of them:

4.1 Wired Connection(Recommended)

1. Connect the camera with power and wait for a moment, until the camera plays a sound "Hello, Foscam".
2. Connect the camera with router by Ethernet cable, and then the camera will play a sound " Wired connection succeed".
3. Make sure your smartphone is connected to your wireless router.
4. Run the Foscam APP on your smartphone, register a Foscam Cloud account then log in. Please follow the steps below to add your camera.



Note: If you have added your IP camera successfully by wired connection, please do not add it again by wireless connection.

4.2 Wireless Connection

Note: Do not connect the camera with router via Ethernet

1. Connect the camera with power and wait for a moment, until the camera plays a sound "Hello, Foscam".
2. Make sure your smartphone is connected to your wireless router.
3. Run the Foscam APP on your smartphone, register a Foscam Cloud account then log in. After the camera plays the sound "Ready for WiFi configuration", please follow the steps below to add your camera.



Note: If you fail to add your camera to smartphone for several times, press the "Reset" button to reset it, or you can refer 4.1 wired connection which is recommended to ensure 100% successful connection.

5 Access the IP Camera

■ Foscam Cloud Service

You can access the camera via Foscam cloud website: ***www.myfoscam.com.***

You can enjoy good experience on this website as below.

- It's quite easy to remotely access and manage all your IP cameras.
- You can enjoy the latest feature firstly on the website, for example cloud storage, video sharing, etc.

If you have already registered an account on Foscam APP, you can directly use this account to log in.

■ Foscam APP

You can use Foscam APP to view the video on your smartphone anytime, anywhere.

Note: You can experience new features, including EZLink, Online-Update, Message Push, etc., ONLY on "Foscam" APP. Any other third-party APP, other than "Foscam", can't support all these new features. If the resolution of your Foscam camera is 1080P, only the "Foscam" APP supports it.

■ Web UI

If you want to manage your camera more professionally, we suggest you to access your camera via browser. You can download the "**Equipment Search Tool**" from ***http://www.foscam.com*** to your computer, then access the camera directly via the search tool.

6 Hardware Installation



1. Rotate the base of the camera until points a and b are aligned, this allows for the mounting plate to be removed.
2. Install the mounting plate on a wall or ceiling with supplied fixing screws.
3. Align points a and b to insert the camera base to the mounting plate. Rotate so that points a and b are no longer aligned, this attaches the camera securely to the base.

7 Important Notice

■ Camera Username / Password

The camera username / password are used to access and manage your camera on computer. They can improve the security of your camera significantly.

If you have forgotten either of them, you need to press and hold the "Reset" button on the camera powered on. After hearing the voice prompt, release the button. The camera will automatically reboot and the default settings will be restored. Then the default username / password become admin / (blank).

After restoring to the factory default settings, you need to delete the camera from Foscam APP, and then add it again.

■ Foscam cloud service Account / Password

Foscam cloud service account / password is used to access Foscam APP or Foscam cloud service website, you can register the account / password on one of them.

■ Storage Media

Support cloud storage, NVR(Network Video Recorder), Micro SD card.

If you hope to video for a whole day, it is suggested to use the Foscam NVR.

■ Firmware Upgrade

You can upgrade the firmware on Foscam APP with new feature "One-key Online Upgrade"(Enter Foscam APP, select "Settings > Firmware Upgrade").

You also can download the latest version to upgrade your camera from office website *http://www.foscam.com* (Select "Support > Download Center > Firmware Downloads").

■ Safety Tips

- Please check whether the power supply is matched before using the camera.
- Please fix the camera and brackets with the provided locating screws to avoid falling down.
- To avoid the risk of fire or electric shock, please keep your camera in dry and cool place, and do not let the camera be affected with damp.
- The camera is electronic equipment, please keep it away from children.
- Change your default port to a greater range to avoid hackers' invasion.
- Check the logs of your Foscam cameras often. Foscam Cameras have embedded logs reminding you which IP addresses are accessing the camera.

8 Technical Support

If you have any problems with your Foscam IP Camera, please contact the Foscam reseller you purchased from. If your problem still can't be solved, please send your e-mail to the technical support team of Foscam headquarter at **tech@foscam.com.**

Your valuable comments and suggestions on improving Foscam products are welcomed!

FOSCAM®

CE Certificate Website:
http://www.foscam.com/company/ce-certificate.html

www.foscam.com